




JOINT ATTACHMENT



Outside snap ring




Inside snap ring



Strap & Bolt

Centering Lug




U-Bolt

Drive Line


End Yoke

Step 3


DETERMINE THE PROPER WORKING LENGTH




Example #1




Example #2



Example #3




Example #4



Example #5


Measure with vehicle weight on suspension.






Need more info, [call](#) or [email us!](#)

Step 2


DETERMINE ATTACHMENT TYPE REQUIRED ON EACH END



Proper U-Joint selection may require measuring the attaching Yoke or U-Joint. Spicer style has centering lugs. Saginaw and Detroit styles are broached flat on inside surface.



END YOKE



On Spicer yokes/joints, dimension E equals the distance between centering lugs or the distance across the U-Joint.

On Saginaw or Detroit yokes/joints, dimension F equals the inside span of yoke or distance between snap rings outside edge.

